INSTRUCTIONS


# **VARIABLE POWER**



www.yukonoptics.com



16-32x50 / 20-50x50 / 20-50x50WA / 20-50x50WA(WP)



# MODEL 16-32x50 20-50x50 20-50x50wa 20-50x50wa(WP) Objective Lens, mm 50 50 50 50 Magnification, x 16-32 20-50 20-50 20-50

Magnification, x Field of view m/ft @ 1000 m/yds Length, mm/in Weight, kg/oz

16-32 20-50 20-50 20-50 45/148 35/115 44/145 44/145 235/9 240/9 240/9 240/9 0,7/25 0,7/25 0,7/25 0,7/25

## INSTRUCTIONS

This manual will help familiarize you with the features, operations and maintenance of the Yukon™ Variable Power spotting scope. The unique design of the scope utilizes the folded light path Newtonian - style reflecting mirror and lens optical system. This design allows the scope to provide high magnification and image quality in a compac 9 - inch long body. The Yukon™ is sold with optional tripod/car window kit. The Waterproof model of the scope can be used in any weather conditions and will continue to work normally after complete submersion in water.

#### **FOCUSING**

- 1. Remove the scope from the carrying case.
- 2. Remove protective lens caps (1) and (3).
- 3. Rotate zoom mechanism (2) to the desired power.
- Adjust the eyepiece until scope comes into focus. With high magnification level you
  may need to use a tripod to control unwanted image vibrations.

#### CARE AND MAINTENANCE

- Your Yukon™ scope is designed to be durable and maintenance free. Clean the rubber-coated body with a cloth rag using a small amount of rubber protectant.
- When cleaning the optics use a light coating of lens cleaning solution on a cotton cloth. Do not pour lens cleaner on the lens itself.
- Condensation on the lens may occur when bringing the scope in from the cold. This is common and within one hour this condition should disappear.
- The Standard model is water resistant. It can be used in inclement weather but should not be submerged as it is water-resistant but not waterproof.

Warning! Never observe the sun either directly or with the optical device.

### LIMITED WARRANTY

The Manufacturer warrants its products against defects in materials and workmanship for a period of three years from the original date of purchase. Any device returned for warranty service must be judged by The Manufacturer as having been used according to its original design intents. As such, misuse, neglect, or any abnormal use is not covered by this warranty. Product malfunction or deterioration due to normal use is not covered by this warranty.

The Manufacturer will repair or replace such products or parts thereof, which, upon inspection by The Manufacturer, is found to be defective in either materials workmanship. As a condition of The Manufacturer's obligation regarding warranty work, the product must be returned to The Manufacturer with satisfactory proof of purchase. It is highly recommended that you fill out and return your warranty registration card to ensure the warranty coverage.

This warranty is null and void if equipment has been altered, tampered with, modified, or otherwise abused, mishandled, or subjected to unauthorized repairs. The manufacturer disclaims any other warranties, either expressed or implied, except as expressed herein, the sole obligation of the manufacturer is to repair or replace the covered device. The manufacturer expressly disclaims responsibility for any lost profits, general, specific, direct, indirect, or consequential damages which may result from breach of any warranty, or resulting from the use, or inability to use, of any the manufacturer's products.